

Sharp AR M455N

1. Locate and press the “Custom Settings” button on the LCD display.
2. Press the “Total Count” button.
3. write down the total count, which is near the top of the display on the left-hand side.
4. Press “OK”
5. Press “Exit”